


























**GIOVENZANA**  
INTERNATIONAL B.V.

**ACTUATORS | PANEL MOUNTING TYPE R | SCREW FIXING**

**SE16 - SE32 SERIES** | EN 60529 - IP65 - UL50 Type 1 - 4 - 4x -12 (◆) Protection NEMA 4x.

 <ul style="list-style-type: none"> <li>➤ Grey Plate</li> <li>➤ Black knob</li> </ul>	<table border="1"> <thead> <tr> <th>SERIES</th> </tr> </thead> <tbody> <tr> <td>SE16 - SE32</td> </tr> </tbody> </table>	SERIES	SE16 - SE32	<table border="1"> <thead> <tr> <th>FRONT PLATE SIZE</th> </tr> </thead> <tbody> <tr> <td>□48</td> </tr> </tbody> </table>	FRONT PLATE SIZE	□48	<table border="1"> <thead> <tr> <th>CODE PANEL MOUNTING TYPE R</th> </tr> </thead> <tbody> <tr> <td>001/0001</td> </tr> </tbody> </table>	CODE PANEL MOUNTING TYPE R	001/0001	<table border="1"> <thead> <tr> <th>LEGEND PLATE</th> </tr> </thead> <tbody> <tr> <td></td> </tr> </tbody> </table>	LEGEND PLATE	
SERIES												
SE16 - SE32												
FRONT PLATE SIZE												
□48												
CODE PANEL MOUNTING TYPE R												
001/0001												
LEGEND PLATE												
												
 <ul style="list-style-type: none"> <li>➤ Grey Plate</li> <li>➤ Black knob</li> <li>➤ Locking Facility (Max 1 lock)</li> </ul>	<table border="1"> <thead> <tr> <th>SERIES</th> </tr> </thead> <tbody> <tr> <td>SE16 - SE32</td> </tr> </tbody> </table>	SERIES	SE16 - SE32	<table border="1"> <thead> <tr> <th>FRONT PLATE SIZE</th> </tr> </thead> <tbody> <tr> <td>□48</td> </tr> </tbody> </table>	FRONT PLATE SIZE	□48	<table border="1"> <thead> <tr> <th>CODE PANEL MOUNTING TYPE R</th> </tr> </thead> <tbody> <tr> <td>003/0001 ◆</td> </tr> </tbody> </table>	CODE PANEL MOUNTING TYPE R	003/0001 ◆	<table border="1"> <thead> <tr> <th>LEGEND PLATE</th> </tr> </thead> <tbody> <tr> <td></td> </tr> </tbody> </table>	LEGEND PLATE	
SERIES												
SE16 - SE32												
FRONT PLATE SIZE												
□48												
CODE PANEL MOUNTING TYPE R												
003/0001 ◆												
LEGEND PLATE												
												
 <ul style="list-style-type: none"> <li>➤ Grey Plate</li> <li>➤ Black knob</li> <li>➤ Locking Facility (Max 3 locks)</li> </ul>	<table border="1"> <thead> <tr> <th>SERIES</th> </tr> </thead> <tbody> <tr> <td>SE16 - SE32</td> </tr> </tbody> </table>	SERIES	SE16 - SE32	<table border="1"> <thead> <tr> <th>FRONT PLATE SIZE</th> </tr> </thead> <tbody> <tr> <td>□67</td> </tr> </tbody> </table>	FRONT PLATE SIZE	□67	<table border="1"> <thead> <tr> <th>CODE PANEL MOUNTING TYPE R</th> </tr> </thead> <tbody> <tr> <td>009/0001 ◆</td> </tr> </tbody> </table>	CODE PANEL MOUNTING TYPE R	009/0001 ◆	<table border="1"> <thead> <tr> <th>LEGEND PLATE</th> </tr> </thead> <tbody> <tr> <td></td> </tr> </tbody> </table>	LEGEND PLATE	
SERIES												
SE16 - SE32												
FRONT PLATE SIZE												
□67												
CODE PANEL MOUNTING TYPE R												
009/0001 ◆												
LEGEND PLATE												
												
 <ul style="list-style-type: none"> <li>➤ Yellow Plate</li> <li>➤ Red knob</li> </ul>	<table border="1"> <thead> <tr> <th>SERIES</th> </tr> </thead> <tbody> <tr> <td>SE16 - SE32</td> </tr> </tbody> </table>	SERIES	SE16 - SE32	<table border="1"> <thead> <tr> <th>FRONT PLATE SIZE</th> </tr> </thead> <tbody> <tr> <td>□48</td> </tr> </tbody> </table>	FRONT PLATE SIZE	□48	<table border="1"> <thead> <tr> <th>CODE PANEL MOUNTING TYPE R</th> </tr> </thead> <tbody> <tr> <td>002/0001</td> </tr> </tbody> </table>	CODE PANEL MOUNTING TYPE R	002/0001	<table border="1"> <thead> <tr> <th>LEGEND PLATE</th> </tr> </thead> <tbody> <tr> <td></td> </tr> </tbody> </table>	LEGEND PLATE	
SERIES												
SE16 - SE32												
FRONT PLATE SIZE												
□48												
CODE PANEL MOUNTING TYPE R												
002/0001												
LEGEND PLATE												
												
 <ul style="list-style-type: none"> <li>➤ Yellow Plate</li> <li>➤ Red knob</li> <li>➤ Locking Facility (Max 1 lock)</li> </ul>	<table border="1"> <thead> <tr> <th>SERIES</th> </tr> </thead> <tbody> <tr> <td>SE16 - SE32</td> </tr> </tbody> </table>	SERIES	SE16 - SE32	<table border="1"> <thead> <tr> <th>FRONT PLATE SIZE</th> </tr> </thead> <tbody> <tr> <td>□48</td> </tr> </tbody> </table>	FRONT PLATE SIZE	□48	<table border="1"> <thead> <tr> <th>CODE PANEL MOUNTING TYPE R</th> </tr> </thead> <tbody> <tr> <td>004/0001 ◆</td> </tr> </tbody> </table>	CODE PANEL MOUNTING TYPE R	004/0001 ◆	<table border="1"> <thead> <tr> <th>LEGEND PLATE</th> </tr> </thead> <tbody> <tr> <td></td> </tr> </tbody> </table>	LEGEND PLATE	
SERIES												
SE16 - SE32												
FRONT PLATE SIZE												
□48												
CODE PANEL MOUNTING TYPE R												
004/0001 ◆												
LEGEND PLATE												
												
 <ul style="list-style-type: none"> <li>➤ Yellow Plate</li> <li>➤ Red knob</li> <li>➤ Locking Facility (Max 3 locks)</li> </ul>	<table border="1"> <thead> <tr> <th>SERIES</th> </tr> </thead> <tbody> <tr> <td>SE16 - SE32</td> </tr> </tbody> </table>	SERIES	SE16 - SE32	<table border="1"> <thead> <tr> <th>FRONT PLATE SIZE</th> </tr> </thead> <tbody> <tr> <td>□67</td> </tr> </tbody> </table>	FRONT PLATE SIZE	□67	<table border="1"> <thead> <tr> <th>CODE PANEL MOUNTING TYPE R</th> </tr> </thead> <tbody> <tr> <td>010/0001 ◆</td> </tr> </tbody> </table>	CODE PANEL MOUNTING TYPE R	010/0001 ◆	<table border="1"> <thead> <tr> <th>LEGEND PLATE</th> </tr> </thead> <tbody> <tr> <td></td> </tr> </tbody> </table>	LEGEND PLATE	
SERIES												
SE16 - SE32												
FRONT PLATE SIZE												
□67												
CODE PANEL MOUNTING TYPE R												
010/0001 ◆												
LEGEND PLATE												
